

Finite Element Theory for PHIMATS

Abdelrahman Hussein

email a.h.a.hussein@outlook.com, abdelrahman.hussein@oulu.fi

February 2025

This document summarizes the main ideas of the finite element method theory and constitutive relations as implemented in the code PHIMATS ([GitHub Repository](#)). Rather than detailing the derivations or specific models, this document focuses on the key mathematical foundations and numerical strategies used within the implementation. For in-depth theoretical discussions, the reader is encouraged to consult the references. For citing this document, please use: [Abdelrahman Hussein. Finite Element Theory for PHIMATS. 2025. doi: 10.48550/ARXIV. 2502.16283]. Hands-on examples can be found in CaseStudies directory on the GitHub repository.

Contents

1	Isoparametric formulation	2
1.1	Derivatives	2
1.2	Numerical integration	3
2	The weak form	3
3	FEM for heat and mass transfer	4
3.1	Constitutive relations	4
3.2	The weak form	5
3.3	FE discretization	5
4	FEM for mesoscale hydrogen transport in metals	5
4.1	Constitutive relations	5
4.2	The weak form	6
4.3	FE discretization	6
5	FEM for small strain isotropic linear elasticity	7
5.1	Constitutive relations	7
5.2	The weak form	8
5.3	FE discretization	9

1 Isoparametric formulation

The geometry of a domain can be discretized by building blocks called elements, that are defined by the nodes forming these elements and their coordinates. The unknown variables of interest are calculated at these nodes, i.e. nodal unknowns or *degrees of freedom (DOFs)*. These unknowns can be interpolated at any location within an element using the so called (interpolation) shape functions. Similarly, shape functions can be used to interpolate the geometry of the element. For the *isoparametric formulation*, the same shape functions are used to interpolate both the geometry and the nodal unknowns [Biner2017].

The shape functions $N_i(\xi)$ are constructed to have the value of 1 for a given node and zero everywhere else. ξ is a non-dimensional coordinate system called *local* or *element* coordinate system, which vary in the range $[-1,1]$. We will use a 4-node quad element as an example for $N_i(\xi)$. For a degree of freedom f with known values at the element nodes f_1, f_2, f_3, f_4 , the value at any point ξ within the element are given by

$$f = \sum_i^n N_i(\xi) f_i = N_1(\xi) f_1 + N_2(\xi) f_2 + N_3(\xi) f_3 + N_4(\xi) f_4 \quad (1.1)$$

Where n is the number of nodes¹ per element.

Box 1.1: Example of shape functions for a 4-node quadrilateral element

$$\begin{aligned} N_1 &= 0.25(1 - \xi)(1 - \eta) \\ N_2 &= 0.25(1 + \xi)(1 - \eta) \\ N_3 &= 0.25(1 + \xi)(1 + \eta) \\ N_4 &= 0.25(1 - \xi)(1 + \eta) \end{aligned}$$

Similarly, any point ξ within the element can be mapped to *cartesian* coordinates by

$$\mathbf{x}(\xi) = \sum_i^n N_i(\xi) \mathbf{x}_i \quad (1.2)$$

Where \mathbf{x}_i are the cartesian coordinates of the nodes.

1.1 Derivatives

The cartesian derivatives² of the variable f at any point ξ defined at the element nodes can be evaluated as

$$\begin{aligned} \frac{\partial f(\xi)}{\partial \mathbf{x}} &= \sum_i^n \frac{\partial N_i(\xi)}{\partial \mathbf{x}} f_i^\top \\ &= \begin{bmatrix} \frac{\partial N_1(\xi)}{\partial x} & \dots & \frac{\partial N_n(\xi)}{\partial x} \\ \frac{\partial N_1(\xi)}{\partial y} & \dots & \frac{\partial N_n(\xi)}{\partial y} \\ \frac{\partial N_1(\xi)}{\partial z} & \dots & \frac{\partial N_n(\xi)}{\partial z} \end{bmatrix} \begin{bmatrix} f_1 \\ \vdots \\ f_n \end{bmatrix} \end{aligned} \quad (1.3)$$

¹ $N_i = \mathbf{N}$ will be represented as a row vector. And since all the shape functions $N_i(\xi)$ have to be evaluated for a given Gauss point ξ , they will be stored for each element as $\text{nGauss} \times \text{nElNodes}$

²Note this is a matrix of dimensions $\text{nDim} \times \text{nElNodes}$.

Using the chain rule

$$\sum_i^n \frac{\partial N_i(\boldsymbol{\xi})}{\partial \mathbf{x}} = \sum_i^n \frac{\partial N_i(\boldsymbol{\xi})}{\partial \boldsymbol{\xi}} \frac{\partial \boldsymbol{\xi}}{\partial \mathbf{x}} \quad (1.4)$$

$\frac{\partial \mathbf{x}(\boldsymbol{\xi})}{\partial \boldsymbol{\xi}} = \frac{\partial x_i(\boldsymbol{\xi})}{\partial \xi_j}$ is called the jacobian matrix $\mathbf{J}(\boldsymbol{\xi})$ with components

$$\mathbf{J}(\boldsymbol{\xi}) = \begin{bmatrix} \frac{\partial x}{\partial \xi} & \frac{\partial x}{\partial \eta} & \frac{\partial x}{\partial \zeta} \\ \frac{\partial y}{\partial \xi} & \frac{\partial y}{\partial \eta} & \frac{\partial y}{\partial \zeta} \\ \frac{\partial z}{\partial \xi} & \frac{\partial z}{\partial \eta} & \frac{\partial z}{\partial \zeta} \end{bmatrix} \quad (1.5)$$

Using Eq. (1.2)

$$\begin{aligned} \mathbf{J}(\boldsymbol{\xi}) &= \sum_i^n \frac{\partial N_i(\boldsymbol{\xi})}{\partial \boldsymbol{\xi}} \mathbf{x}_i^\top \\ &= \begin{bmatrix} \frac{\partial N_1(\boldsymbol{\xi})}{\partial x} & \dots & \frac{\partial N_n(\boldsymbol{\xi})}{\partial x} \\ \frac{\partial N_1(\boldsymbol{\xi})}{\partial y} & \dots & \frac{\partial N_n(\boldsymbol{\xi})}{\partial y} \\ \frac{\partial N_1(\boldsymbol{\xi})}{\partial z} & \dots & \frac{\partial N_n(\boldsymbol{\xi})}{\partial z} \end{bmatrix} \begin{bmatrix} x_1 & y_1 & z_1 \\ \vdots & \vdots & \vdots \\ x_n & y_n & z_n \end{bmatrix} \end{aligned} \quad (1.6)$$

Substituting in Eq. (1.4)

$$\sum_i^n \frac{\partial N_i(\boldsymbol{\xi})}{\partial \mathbf{x}} = \mathbf{J}(\boldsymbol{\xi})^{-1} \sum_i^n \frac{\partial N_i(\boldsymbol{\xi})}{\partial \boldsymbol{\xi}} \quad (1.7)$$

It is worth noting that the volume/area mapping can be obtained using

$$d\mathbf{x} = \det[\mathbf{J}(\boldsymbol{\xi})] d\boldsymbol{\xi} \quad (1.8)$$

1.2 Numerical integration

Gauss quadrature is used for integration over the element domain (in local coordinates) of the form

$$\begin{aligned} \int_{-1}^{+1} \int_{-1}^{+1} \int_{-1}^{+1} f(\boldsymbol{\xi}) d\boldsymbol{\xi} &= \int_{\Omega_e} f(\boldsymbol{\xi}) d\boldsymbol{\xi} \approx \sum_{I=1}^M \sum_{J=1}^M \sum_{K=1}^M w_I w_J w_K f(\boldsymbol{\xi}) \\ &\approx \sum_{I=1}^M \sum_{J=1}^M \sum_{K=1}^M w_I w_J w_K f(\xi_I, \eta_J, \zeta_K) \end{aligned} \quad (1.9)$$

Where $w_{I,J,K}$ is the weight of the the integration point $\boldsymbol{\xi}$. Therefore, the volume integral over all the element can be taken as the summation of volume integral of all its gauss points.

2 The weak form

The FEM method for solving a PDE starts with forming a variational principle transforming the *strong form* to *weighted-residual* or a *weak form*. This "weak form" transforms the PDE problem to a minimization problem. This involves the following steps [Biner2017]:

1. Multiply the PDE with a *test* function. In the Galerkin FEM, the test function is the "trial" function.

2. Integrate over the whole domain Ω .
3. Integrate by parts the terms involving spatial gradients using the divergence theorem.
4. Provide the given boundary conditions.

A general case for integration by parts

$$\int_{\Omega} \psi(\nabla \cdot \nabla u) d\Omega = - \int_{\Omega} \nabla \psi \cdot \nabla u d\Omega + \int_{\Gamma} \psi(\nabla u \cdot \mathbf{n}) d\Gamma \quad (2.1)$$

For example, consider the PDE

$$\frac{\partial C}{\partial t} + \nabla \cdot D(\mathbf{x}) \nabla C = 0 \quad (2.2)$$

Step(1): Multiply Eq. (2.2) by a test function ψ

$$\psi \left(\frac{\partial C}{\partial t} \right) + \psi(\nabla \cdot D(\mathbf{x}) \nabla C) = 0 \quad (2.3)$$

Step(2): Integrate over the domain

$$\int_{\Omega} \psi \left(\frac{\partial C}{\partial t} \right) d\Omega + \int_{\Omega} \psi(\nabla \cdot D(\mathbf{x}) \nabla C) d\Omega = 0 \quad (2.4)$$

Step(3): Integrate by parts the terms involving gradients, i.e. the second term of the lhs

$$\int_{\Omega} \psi(\nabla \cdot D(\mathbf{x}) \nabla C) d\Omega = - \int_{\Omega} \nabla \psi \cdot D(\mathbf{x}) \nabla C d\Omega + \int_{\Gamma} \psi(D(\mathbf{x}) \nabla C \cdot \mathbf{n}) d\Gamma \quad (2.5)$$

Step(4): Note that the flux $\mathbf{J} = D(\mathbf{x}) \nabla C$. Some parts of the boundary Γ_1 will have known \mathbf{J}_{Γ_1} (Neumann boundary conditions), while some other parts will have prescribed concentration C_{Γ_2} (Dirichlet boundary conditions). Thus, the surface integral of Eq. (2.5) becomes

$$\int_{\Gamma} \psi(\mathbf{J} \cdot \mathbf{n}) d\Gamma = \int_{\Gamma_1} \psi(\mathbf{J}_{\Gamma_1} \cdot \mathbf{n}) d\Gamma_1 \quad (2.6)$$

The weak form of Eq. (2.2) becomes

$$\int_{\Omega} \psi \left(\frac{\partial C}{\partial t} \right) d\Omega - \int_{\Omega} \nabla \psi \cdot D(\mathbf{x}) \nabla C d\Omega + \int_{\Gamma_1} \psi(\mathbf{J}_{\Gamma_1} \cdot \mathbf{n}) d\Gamma_1 = 0 \quad (2.7)$$

3 FEM for heat and mass transfer

3.1 Constitutive relations

The transient heat transfer is expressed as

$$\rho s \frac{\partial T}{\partial t} - \nabla \cdot (\mathbf{k} \nabla T) - Q \quad (3.1)$$

Where ρ is the mass density, c is the heat capacity, Q is the heat generated per unit volume per unit time³ and \mathbf{k} is the conductivity matrix

$$\begin{bmatrix} k_x & 0 & 0 \\ 0 & k_y & 0 \\ 0 & 0 & k_z \end{bmatrix} \quad (3.2)$$

³source/sink

3.2 The weak form

The weak form is

$$\int_{\Omega} \delta T^* \rho s \frac{\partial T}{\partial t} d\Omega + \int_{\Omega} \nabla \delta T^* \mathbf{k} \nabla T d\Omega - \int_{\Omega} \delta T^* Q d\Omega - \int_{\Gamma_2} \delta T^* (\mathbf{J}_{\Gamma_2} \cdot \mathbf{n}) d\Gamma_2 = 0 \quad (3.3)$$

3.3 FE discretization

Using

$$T(\boldsymbol{\xi}) = \sum_i^n N_i(\boldsymbol{\xi}) T_i \quad \nabla T(\boldsymbol{\xi}) = \sum_i^n \mathbf{B}_i(\boldsymbol{\xi}) T_i \quad (3.4)$$

Substituting in Eq. (3.3)⁴, and eliminating δT^*

$$\int_{\Omega} \mathbf{N}^T \rho s \mathbf{N} \frac{\partial T}{\partial t} d\Omega + \int_{\Omega} \mathbf{B}^T \mathbf{k} \mathbf{B} T d\Omega - \int_{\Omega} \mathbf{N}^T Q d\Omega - \int_{\Gamma_2} \mathbf{N}^T (\mathbf{J}_{\Gamma_2} \cdot \mathbf{n}) d\Gamma_2 = 0 \quad (3.5)$$

Where the capacity matrix \mathbf{C}

$$\mathbf{C} = \int_{\Omega} \mathbf{N}^T \rho c \mathbf{N} d\Omega \quad (3.6)$$

And the conductivity matrix \mathbf{K}

$$\mathbf{K}_c = \int_{\Omega} \mathbf{B}^T \mathbf{k} \mathbf{B} d\Omega \quad (3.7)$$

Eq. (3.5) can then be expressed as

$$\mathbf{C} \dot{\mathbf{T}} + \mathbf{K}_c \mathbf{T} = \mathbf{F} \quad (3.8)$$

The implicit time integration of Eq. (3.9) can be done as

$$(\mathbf{C} + \Delta t \mathbf{K}_c) \mathbf{T}^{t+1} = \Delta t \mathbf{F} + \mathbf{M} \mathbf{T}^t \quad (3.9)$$

4 FEM for mesoscale hydrogen transport in metals

4.1 Constitutive relations

The total flux for hydrogen transport, interface $g(\phi)_{\text{intf}}$ [Hussein2024, Hussein2024b] and phase ϕ_j interaction

$$\mathbf{J} = -\mathbf{D} \left(\nabla c - \frac{\zeta_{\text{intf}} c}{RT} \nabla g(\phi)_{\text{intf}} - \frac{\zeta_j c}{RT} \nabla \phi_j \right) \quad (4.1)$$

And by applying the mass conservation

$$\frac{\partial c}{\partial t} - \nabla \cdot \mathbf{D} \left(\nabla c - \frac{\zeta_{\text{intf}} c}{RT} \nabla g(\phi)_{\text{intf}} - \frac{\zeta_j c}{RT} \nabla \phi_j \right) = 0 \quad (4.2)$$

⁴To simplify the notation, $\sum_i^n N_i(\boldsymbol{\xi}) T_i \equiv \mathbf{N} T$ is used with the understanding that T is the element nodal values.

4.2 The weak form

Multiply Eq. (4.2) by a test function η and integrate over the domain

$$\int_{\Omega} \eta \left(\frac{\partial c}{\partial t} \right) d\Omega - \int_{\Omega} \eta \nabla \cdot \mathbf{D} \left(\nabla c - \frac{\zeta_{\text{intf}} c}{RT} \nabla g(\phi)_{\text{intf}} - \frac{\zeta_j c}{RT} \nabla \phi_j \right) d\Omega = 0 \quad (4.3)$$

Integrate by parts the second term of the LHS and combining all, the weak form of Eq. (4.2) becomes

$$\int_{\Omega} \eta \frac{\partial c}{\partial t} d\Omega + \int_{\Omega} \nabla \eta \cdot \mathbf{D} \left(\nabla c - \frac{\zeta_{\text{intf}} c}{RT} \nabla g(\phi)_{\text{intf}} - \frac{\zeta_j c}{RT} \nabla \phi_j \right) d\Omega = \int_{\Gamma} \eta \mathbf{J} \cdot \mathbf{n} d\Gamma \quad (4.4)$$

4.3 FE discretization

Using

$$\begin{aligned} c &= \mathbf{N} \mathbf{c} & \nabla c &= \mathbf{B} \mathbf{c} \\ \nabla g(\phi)_{\text{intf}} &= \mathbf{B} \mathbf{g}(\phi)_{\text{intf}} & \nabla \phi_j &= \mathbf{B} \phi_j \end{aligned} \quad (4.5)$$

And substituting in 4.4

$$\begin{aligned} \int_{\Omega} \mathbf{N}^T \boldsymbol{\eta}^T \frac{\partial}{\partial t} (\mathbf{N} \mathbf{c}) d\Omega + \int_{\Omega} \mathbf{B}^T \boldsymbol{\eta}^T \mathbf{D} \mathbf{B} \mathbf{c} d\Omega - \int_{\Omega} \mathbf{B}^T \boldsymbol{\eta}^T \mathbf{D} \frac{\zeta_{\text{intf}}}{RT} \mathbf{B} \mathbf{g}(\phi)_{\text{intf}} \mathbf{N} \mathbf{c} d\Omega \\ - \int_{\Omega} \mathbf{B}^T \boldsymbol{\eta}^T \mathbf{D} \frac{\zeta_j}{RT} \mathbf{B} \phi_j \mathbf{N} \mathbf{c} d\Omega - \int_{\Gamma} \mathbf{N}^T \boldsymbol{\eta}^T (\mathbf{J} \cdot \mathbf{n}) d\Gamma = 0 \end{aligned} \quad (4.6)$$

By eliminating $\boldsymbol{\eta}^T$, we finally get

$$\begin{aligned} \int_{\Omega} \mathbf{N}^T \frac{\partial}{\partial t} (\mathbf{N} \mathbf{c}) d\Omega + \int_{\Omega} \mathbf{B}^T \mathbf{D} \mathbf{B} \mathbf{c} d\Omega - \int_{\Omega} \mathbf{B}^T \mathbf{D} \frac{\zeta_{\text{intf}}}{RT} \mathbf{B} \mathbf{g}(\phi)_{\text{intf}} \mathbf{N} \mathbf{c} d\Omega \\ - \int_{\Omega} \mathbf{B}^T \mathbf{D} \frac{\zeta_j}{RT} \mathbf{B} \phi_j \mathbf{N} \mathbf{c} d\Omega - \int_{\Gamma} \mathbf{N}^T (\mathbf{J} \cdot \mathbf{n}) d\Gamma = 0 \end{aligned} \quad (4.7)$$

Where mass matrix \mathbf{M}

$$\mathbf{M} = \int_{\Omega} \mathbf{N}^T \mathbf{N} d\Omega \quad (4.8)$$

And the diffusivity matrix \mathbf{K}_D

$$\mathbf{K}_D = \int_{\Omega} \mathbf{B}^T \mathbf{D} \mathbf{B} d\Omega \quad (4.9)$$

And the interaction matrix \mathbf{K}_I

$$\mathbf{K}_I = \int_{\Omega} \mathbf{B}^T \mathbf{D} \frac{\zeta_{\text{intf}}}{RT} \mathbf{B} \mathbf{g}(\phi)_{\text{intf}} \mathbf{N} d\Omega + \int_{\Omega} \mathbf{B}^T \mathbf{D} \frac{\zeta_j}{RT} \mathbf{B} \phi_j \mathbf{N} d\Omega \quad (4.10)$$

Eq. (4.7) can then be expressed as

$$\mathbf{M} \dot{\mathbf{c}} + [\mathbf{K}_D - \mathbf{K}_I] \mathbf{c} = \mathbf{F} \quad (4.11)$$

The implicit time integration of Eq. (4.11) can be done as

$$\frac{\mathbf{c}^{t+1} - \mathbf{c}^t}{\Delta t} \mathbf{M} + \mathbf{K}_D \mathbf{c}^{t+1} - \mathbf{K}_I \mathbf{c}^{t+1} = \mathbf{F} \quad (4.12)$$

$$[\mathbf{M} + \Delta t \mathbf{K}_D - \Delta t \mathbf{K}_I] \mathbf{c}^{t+1} = \Delta t \mathbf{F} + \mathbf{M} \mathbf{c}^t \quad (4.13)$$

Note that Eq. (4.13) is linear and can be solved with linear solvers.

5 FEM for small strain isotropic linear elasticity

5.1 Constitutive relations

The stress-strain relations for isotropic linear elasticity are

$$\begin{aligned} \boldsymbol{\sigma} &= \mathbf{C} \boldsymbol{\varepsilon} \\ \sigma_{ij} &= C_{ijkl} \varepsilon_{kl} \end{aligned} \quad (5.1)$$

Using the Lamé constants $\lambda = E\nu/(1+\nu)$ and $\mu = G = E/2(1+\nu)$

$$\boldsymbol{\sigma} = 2G\boldsymbol{\varepsilon} + \lambda \text{Tr}(\boldsymbol{\varepsilon})\mathbf{I} \quad (5.2)$$

And in component form

$$\begin{bmatrix} \sigma_{xx} & \sigma_{xy} & \sigma_{xz} \\ \sigma_{yx} & \sigma_{yy} & \sigma_{yz} \\ \sigma_{zx} & \sigma_{zy} & \sigma_{zz} \end{bmatrix} = 2G \begin{bmatrix} \varepsilon_{xx} & \varepsilon_{xy} & \varepsilon_{xz} \\ \varepsilon_{yx} & \varepsilon_{yy} & \varepsilon_{yz} \\ \varepsilon_{zx} & \varepsilon_{zy} & \varepsilon_{zz} \end{bmatrix} + \lambda(\varepsilon_{xx} + \varepsilon_{yy} + \varepsilon_{zz}) \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix} \quad (5.3)$$

For numerical convenience, it is more practical to represent the stress-strain relations in *Voigt* notation, where the shear components are stored as *engineering* shears.

$$\begin{aligned} \begin{bmatrix} \sigma_{xx} \\ \sigma_{yy} \\ \sigma_{zz} \\ \sigma_{xy} \\ \sigma_{yz} \\ \sigma_{xz} \end{bmatrix} &= \begin{bmatrix} \lambda + 2\mu & \lambda & \lambda & 0 & 0 & 0 \\ \lambda & \lambda + 2\mu & \lambda & 0 & 0 & 0 \\ \lambda & \lambda & \lambda + 2\mu & 0 & 0 & 0 \\ 0 & 0 & 0 & \mu & 0 & 0 \\ 0 & 0 & 0 & 0 & \mu & 0 \\ 0 & 0 & 0 & 0 & 0 & \mu \end{bmatrix} \begin{bmatrix} \varepsilon_{xx} \\ \varepsilon_{yy} \\ \varepsilon_{zz} \\ 2\varepsilon_{xy} \\ 2\varepsilon_{yz} \\ 2\varepsilon_{xz} \end{bmatrix} \\ &= \begin{bmatrix} \lambda + 2\mu & \lambda & \lambda & 0 & 0 & 0 \\ \lambda & \lambda + 2\mu & \lambda & 0 & 0 & 0 \\ \lambda & \lambda & \lambda + 2\mu & 0 & 0 & 0 \\ 0 & 0 & 0 & \mu & 0 & 0 \\ 0 & 0 & 0 & 0 & \mu & 0 \\ 0 & 0 & 0 & 0 & 0 & \mu \end{bmatrix} \begin{bmatrix} \varepsilon_{xx} \\ \varepsilon_{yy} \\ \varepsilon_{zz} \\ \gamma_{xy} \\ \gamma_{yz} \\ \gamma_{xz} \end{bmatrix} \end{aligned} \quad (5.4)$$

For plane-strain

$$\begin{bmatrix} \sigma_{xx} \\ \sigma_{yy} \\ \sigma_{xy} \end{bmatrix} = \frac{E}{(1+\nu)(1-2\nu)} \begin{bmatrix} 1-\nu & \nu & 0 \\ \nu & 1-\nu & 0 \\ 0 & 0 & \frac{1-2\nu}{2} \end{bmatrix} \begin{bmatrix} \varepsilon_{xx} \\ \varepsilon_{yy} \\ \gamma_{xy} \end{bmatrix} \quad (5.5)$$

$\sigma_{zz} \neq 0^5$ and is calculated from

⁵In PHIMATS, σ_{zz} is an output for plasticity models. However, it is not an output for elasticity models, yet, it could be evaluated in post-processing.

$$\sigma_{zz} = \nu(\sigma_{xx} + \sigma_{yy}) \quad (5.6)$$

And for plane-stress

$$\begin{bmatrix} \sigma_{xx} \\ \sigma_{yy} \\ \sigma_{xy} \end{bmatrix} = \frac{E}{(1-\nu^2)} \begin{bmatrix} 1 & \nu & 0 \\ \nu & 1 & 0 \\ 0 & 0 & \frac{1-\nu}{2} \end{bmatrix} \begin{bmatrix} \varepsilon_{xx} \\ \varepsilon_{yy} \\ \gamma_{xy} \end{bmatrix} \quad (5.7)$$

Note that $\varepsilon_{zz} \neq 0$ and is calculated from

$$\varepsilon_{zz} = -\frac{1}{3E}(\sigma_{xx} + \sigma_{yy}) \quad (5.8)$$

Accordingly, the hydrostatic stress σ_h for plane-strain

$$\sigma_h = \frac{1+\nu}{3}(\sigma_{xx} + \sigma_{yy}) \quad (5.9)$$

And for plane-stress

$$\sigma_h = \frac{1}{3}(\sigma_{xx} + \sigma_{yy}) \quad (5.10)$$

5.2 The weak form

The quasi-static balance of linear momentum is

$$\begin{aligned} \nabla \cdot \boldsymbol{\sigma} + \mathbf{b} &= 0 \\ \frac{\partial \sigma_{ij}}{\partial x_j} + b_i &= 0 \end{aligned} \quad (5.11)$$

The problem statement for quasi-static linear elasticity is find u_i , ε_{ij} and σ_{ij} that satisfies

1. The strain-displacement relation $\varepsilon_{ij} = 1/2(\partial u_i/\partial x_j + \partial u_j/\partial x_i)$
2. The stress-strain relation $\sigma_{ij} = C_{ijkl}\varepsilon_{kl}$
3. The quasi-static linear balance of momentum $\frac{\partial \sigma_{ij}}{\partial x_j} + b_i = 0$
4. The displacement and traction boundary conditions $u_i = u_i^{\Gamma_1}$ on Γ_1 and $\sigma_{ij}n_j = t_i^{\Gamma_2}$ on Γ^2

The principle of virtual work is an equivalent integral form of the linear balance of momentum PDE. This makes it more convenient for numerical solution using computers. This essentially involves all the 4-steps mentioned in section 2. We multiply the strong form Eq. (5.11) by a kinematically admissible virtual displacement field δu_i (test function), which means it satisfies $\delta u_i = 0$ on Γ^1 . Following Bower [Bower2009], *This is a complicated way for saying that the small perturbation displacement δu_i satisfies the boundary conditions.* The associated virtual strain field

$$\delta \varepsilon_{ij} = 1/2(\partial \delta u_i/\partial x_j + \partial \delta u_j/\partial x_i) \quad (5.12)$$

The weak form is then

$$\int_{\Omega} \delta \varepsilon_{ji} \sigma_{ij} d\Omega - \int_{\Omega} \delta u_j b_j d\Omega - \int_{\Gamma^2} \delta u_j t_j d\Gamma = 0 \quad (5.13)$$

$$\int_{\Omega} \delta \boldsymbol{\varepsilon}^T \boldsymbol{\sigma} d\Omega - \int_{\Omega} \delta \mathbf{u}^T \mathbf{b} d\Omega - \int_{\Gamma^2} \delta \mathbf{u}^T \mathbf{t} d\Gamma = 0 \quad (5.14)$$

Will satisfy the strong form for all possible $\delta \mathbf{u}$.

5.3 FE discretization

The displacements $\mathbf{u}(\boldsymbol{\xi})$ within any point in the element $\boldsymbol{\xi}$ is obtained from the nodal values of the element using the isoparametric formalism

$$\mathbf{u}(\boldsymbol{\xi}) = \begin{bmatrix} u_x(\boldsymbol{\xi}) \\ u_y(\boldsymbol{\xi}) \\ u_z(\boldsymbol{\xi}) \end{bmatrix} = \sum_i^n N_i(\boldsymbol{\xi}) u_i \quad (5.15)$$

The strains can be obtained from the derivatives of the nodal displacements. For simplicity, we use a 2D case. The small-strain displacement in Voigt notation becomes

$$\boldsymbol{\varepsilon} = \begin{bmatrix} \varepsilon_{xx} \\ \varepsilon_{yy} \\ \gamma_{xy} \end{bmatrix} = \begin{bmatrix} \frac{\partial u_x}{\partial x} \\ \frac{\partial u_y}{\partial y} \\ \frac{\partial u_x}{\partial y} + \frac{\partial u_y}{\partial x} \end{bmatrix} \quad (5.16)$$

Using the displacement values from Eq. (5.15), the strains could be evaluated using the cartesian derivatives of the shape functions similar to Eq. (1.3). However, due to the special case of the Voigt representation of the strain tensor, the cartesian derivatives of the shape functions are collected in a matrix called the \mathbf{B} matrix⁶, which has a special form as will be described later. Therefore

$$\boldsymbol{\varepsilon}(\boldsymbol{\xi}) = \sum_i^n \mathbf{B}_i(\boldsymbol{\xi}) u_i \quad (5.17)$$

Box 5.1: Example for calculating strain in 4-node quad element

$$\begin{bmatrix} \varepsilon_{xx} \\ \varepsilon_{yy} \\ \gamma_{xy} \end{bmatrix} = \begin{bmatrix} \frac{\partial N_1}{\partial x} & 0 & \frac{\partial N_2}{\partial x} & 0 & \frac{\partial N_3}{\partial x} & 0 & \frac{\partial N_4}{\partial x} & 0 \\ 0 & \frac{\partial N_1}{\partial y} & 0 & \frac{\partial N_2}{\partial y} & 0 & \frac{\partial N_3}{\partial y} & 0 & \frac{\partial N_4}{\partial y} \\ \frac{\partial N_1}{\partial y} & \frac{\partial N_1}{\partial x} & \frac{\partial N_2}{\partial y} & \frac{\partial N_2}{\partial x} & \frac{\partial N_3}{\partial y} & \frac{\partial N_3}{\partial x} & \frac{\partial N_4}{\partial y} & \frac{\partial N_4}{\partial x} \end{bmatrix} \begin{bmatrix} u1_x \\ u1_y \\ u2_x \\ u2_y \\ u3_x \\ u3_y \\ u4_x \\ u4_y \end{bmatrix}$$

Using

$$\delta \mathbf{u} = \sum_i^n N_i(\boldsymbol{\xi}) \delta u_i \quad (5.18)$$

And

$$\delta \boldsymbol{\varepsilon} = \sum_i^n \mathbf{B}_i(\boldsymbol{\xi}) \delta u_i \quad (5.19)$$

The weak form in Eq. (5.14) can be written as

⁶Note that \mathbf{B} is of size $\text{nStres} \times \text{nElDispDofs}$, where nStres is the number of stress components and nElDispDofs is the number of displacement degrees of freedom per element. This will have to be evaluated for every gauss point $\boldsymbol{\xi}$, i.e. stored in size nGaus .

$$\int_{\Omega} \mathbf{B}^T \delta \mathbf{u}^T \boldsymbol{\sigma} d\Omega - \int_{\Omega} \mathbf{N}^T \delta \mathbf{u}^T \mathbf{b} d\Omega - \int_{\Gamma^2} \mathbf{N}^T \mathbf{u}^T \mathbf{t} d\Gamma^2 = 0 \quad (5.20)$$

Using the stress-strain relations and eliminating the arbitrary $\delta \mathbf{u}$

$$\int_{\Omega} \mathbf{B}^T \boldsymbol{\sigma} d\Omega - \int_{\Omega} \mathbf{N}^T \mathbf{b} d\Omega - \int_{\Gamma^2} \mathbf{N}^T \mathbf{t} d\Gamma^2 = 0 \quad (5.21)$$

$$\int_{\Omega} \mathbf{B}^T \mathbf{D} \mathbf{B} \mathbf{u} d\Omega - \int_{\Omega} \mathbf{N}^T \mathbf{b} d\Omega - \int_{\Gamma^2} \mathbf{N}^T \mathbf{t} d\Gamma^2 = 0 \quad (5.22)$$

Ignoring body forces

$$\int_{\Omega} \mathbf{B}^T \mathbf{D} \mathbf{B} \mathbf{u} d\Omega - \int_{\Gamma^2} \mathbf{N}^T \mathbf{t} d\Gamma^2 = 0 \quad (5.23)$$

Or

$$\mathbf{f}_{\text{int}} - \mathbf{f}_{\text{ext}} = 0 \quad (5.24)$$

The stiffness matrix \mathbf{K}

$$\mathbf{K} = \int_{\Omega} \mathbf{B}^T \mathbf{D} \mathbf{B} d\Omega \quad (5.25)$$

Since the domain is discretized in n_{Elem} elements and introducing the element stiffness matrix $\mathbf{k}^{(e)}$, the *global* stiffness matrix becomes

$$\mathbf{K} = \sum_{e=1}^{n_{\text{Elem}}} \mathbf{k}^{(e)} \quad (5.26)$$

The element stiffness matrix can be defined as

$$\mathbf{k}^{(e)} = \int_{\Omega_{(e)}} \left[\sum_i^n \mathbf{B}_i(\boldsymbol{\xi}) \right]^T \mathbf{D} \sum_i^n \mathbf{B}_i(\boldsymbol{\xi}) d\Omega_{(e)} \quad (5.27)$$

Where the integral can be evaluated using the gauss quadrature. The reaction force can then be calculated from

$$\mathbf{f}_{\text{reaction}} = -\mathbf{f}_{\text{int}} = - \int_{\Omega} \mathbf{B}^T \boldsymbol{\sigma} d\Omega \quad (5.28)$$