Probability distribution function of crossover frequency of operational amplifiers in the framework of Manhattan equation for the operational amplifier

Todor M. Mishonov^{1,2}, Vladimir G. Marinov¹, Victor I. Danchev¹, Emil G. Petkov¹, Aleksander P. Petkov¹,

Iglika M. Dimitrova³, Vassil N. Gourev⁴, Nikola S. Serafimov⁵, Aleksander A. Stefanov^{6,7}, and

Albert M. Varonov^{8,9}

Abstract—For the first time in electronics we represent experimental data for probability distribution function of the crossover frequency of operational amplifiers. We use 400 (200 double) ADA4898-2 low noise amplifiers. We present an innovative method for determination of crossover frequency which requires an USB lock-in with automatic frequency sweep. Our method is based on a differential equation relating the voltage at the output of an operational amplifier U_0 and the difference between the input voltages $(U_+ \text{ and } U_-)$ which has been derived. The crossover frequency f_0 is a parameter in this operational amplifier master equation. The formulae derived as a consequence of this equation find applications in thousands of specifications for electronic devices but as far as we know, the time dependent equation has never been published. Actually, the master equation of operational amplifiers can be found in the seminal article by Ragazzini, Randall and Russell [J. R. Ragazzini, R. H. Randall and F. A. Russell, "Analysis of Problems in Dynamics by Electronic Circuits", Proc. of the I.R.E. 35, no. 5, pp. 444-452, (1947); Eq. (6), Eq. (7), Eq. (32)], but for more than 70 years it was not analyzed and cited in journals and specifications of operational amplifiers. During World War II, John Ragazzini was involved in the Manhattan Project ["John Ragazzini, 76, Educator and Engineer", The New York Times, November 24, 1988] working on significant projects in the field of electronics and therefore it would be deservedly to say that the master equation we propose is "Manhattan equation" for operational amplifiers. The exact knowledge of the crossover frequency f_0 is necessary when we need to precisely determine the non-ideal effects of operational amplifiers. For instance, in cases when there is a need of an exact calculation of the pass bandwidth of amplifiers with active filters, the Manhattan equation is indispensable.

I. INTRODUCTION

The non-inverting amplifier is one of the most frequently used circuits in electronics. We will not cover it with thousands of references but we will confine our attention to a singular example. The specifications of ADA4817 [1, Eq. (4)] gives the

¹Faculty of Physics, St. Clement of Ohrid University at Sofia, 5 James Bourchier Blvd., BG-1164 Sofia, Bulgaria

²email: mishonov@bgphysics.eu

³Faculty of Chemical Technologies, University of Chemical Technology and Metallurgy, 8, Kliment Ohridski Blvd., BG-1756 Sofia

⁴Department of Atomic Physics, Faculty of Physics, St. Clement of Ohrid University at Sofia, 5 James Bourchier Blvd., BG-1164 Sofia, Bulgaria

⁵Faculty of Telecommunications, Technical University Sofia, 8 Kliment Ohridski Blvd., BG-1000 Sofia, Bulgaria

⁶Faculty of Mathematics, St. Clement of Ohrid University at Sofia, 5 James Bourchier Blvd., BG-1164 Sofia, Bulgaria

⁷Institute of Mathematics and Informatics, Bulgarian Academy of Sciences, Acad. Georgi Bonchev Str., Block 8, BG-1113 Sofia, Bulgaria

⁸Laboratory for fundamental constants measurement, Faculty of Physics, Sofia University, 5 James Bourchier Blvd., BG-1164 Sofia, Bulgaria

⁹avaronov@phys.uni-sofia.bg

frequency-dependent amplification $\Upsilon(\omega)$, which is the ratio between the output U_0 and input U_I voltages, as

$$\mathbf{f}(\omega) = \frac{U_0}{U_{\mathrm{I}}} = \frac{1}{\left(\frac{r}{R+r}\right) + s\tau_0},\tag{1}$$

where (after some change in notation): r is the gain resistance; R is the feedback resistance; ω is the angular frequency and τ_0 is the time-constant, parameterized by the crossover frequency

$$f_0 = \frac{1}{2\pi\tau_0}, \qquad f = \frac{\omega}{2\pi}, \qquad s = j\omega, \tag{2}$$

and j = -i is the imaginary unit more frequently used in electronics. In the physics of waves plane wave has amplitude $\propto e^{i(\mathbf{k}\cdot\mathbf{r}-\omega t)}$, but in the low-frequency electronics minus sign is absorbed in change of the notations $e^{-i\omega t} = e^{j\omega t}$; that is why j = -i. It is interesting to compare this result and the well-known amplification formula from the well known monograph [2, chap. 3, Fig. 3.6b, Eq. (3.12)]

$$\Upsilon(\omega) = \frac{U_0}{U_{\rm I}} = \frac{1}{\left(\frac{r}{R+r}\right) + G^{-1}(\omega)},\tag{3}$$

where $G(\omega)$ is the frequency-dependent open-loop gain of the operational amplifier, used in the relation

$$U_{+} - U_{-} = G^{-1}(\omega)U_{0} \tag{4}$$

between the input and output voltages. The function $\Upsilon(\omega)$ is a complex function from real argument. The comparison between Eq. (1) and Eq. (3) shows that

$$G^{-1}(\omega) = j\omega\tau_0 + \frac{1}{G_0} = s\tau_0 + \frac{1}{G_0}, \quad s = j\omega$$
 (5)

where the DC open-loop gain $G_0 \gg 1$ and the second term is negligible in any high-frequency applications. This equation can be found in numerous monographs, for instance cf. Ref. [3, Chap. 2, Eqs. (2.7a) and (2.7b)]. Here we suppose that all voltages are sinusoidal $U \propto e^{j\omega t}$. In time representation for arbitrary time dependence of the voltages U(t) one can introduce notation for the time differentiation $\hat{s} = \frac{d}{dt}$ and in this case s is its eigenvalue

 \hat{s}

$$e^{j\omega t} = s e^{j\omega t}.$$
 (6)

II. MASTER EQUATION FOR OPERATIONAL AMPLIFIERS

Practically all textbook in electronics are written in the frequency representation, see for example the nice monograph by Dostal [3, Chap. 5, pp. 132-171, Chap. 7, p. 202]. and some of them have even time domain considerations, see the Laplace transform considered in Ref. [4, Chap. 9, Eqs. (9.131-9.133)].

It is trivially to convert form frequency to time representation, but in some sense time representation is in the beginning. The fundamental lows in the physics are related with time evolution. Imagine a textbook in electrodynamics written in frequency representation. For electronic is the same and in many problems we need to use time representation and to solve differential equation. For this purposes we need to make the transition

$$G^{-1}(\omega) = \frac{1}{G_0} + j\omega\tau_0 \quad \to \quad \hat{G}^{-1} = \frac{1}{G_0} + \tau_0 \frac{d}{dt}$$
(7)

and such way we obtain the master equation of all operational amplifiers

$$U_{+}(t) - U_{-}(t) = \hat{G}^{-1}U_{0}(t) = \left(\frac{1}{G_{0}} + \tau_{0}\frac{\mathrm{d}}{\mathrm{d}t} + \dots\right)U_{0}(t).$$
(8)

This equation is well-known to the majority of electrical engineers, see for example the book by Siebert [5]. Here dots means the next terms in the Taylor expansion with respect of time derivatives, which are as a rule negligible when amplification of the circuit is significant.

Despite the fact that this master equation is implicitly present in tens of thousands of publications in electronics, it has never been published in explicit form. Perhaps the first hints of such a dependence have been given by Hendrik Bode [6] see also the work by Peterson [7], but the term operational amplifier had yet been canonized at that time. Coining the term operational amplifier [8, page H.16], John Ragazzini [9, Eq. (6), Eq. (7), Eq. (32)] summarizes the experience of significant engineering developments from the Manhattan project [10] and therefore it would be deservedly to say that Eq. (8) is "Manhattan equation" for operational amplifiers.

III. APPLICABILITY OF THE LOW FREQUENCY APPROXIMATION

In more that 51% of its applications, operational amplifiers are used in closed loop circuit with significant amplification much bigger than one. In this case the frequency domain is significantly reduced by the amplification. Only in this wellknown approximations are derived the well-known formulas for frequency dependent amplification of inverting and noninverting amplifiers given in the specification of ADA4817 [1, Eqs. (4,7), Fig. 54]. In order to clarify the terminology, we have to point out that the low-frequency approximation is parameterized by time constant τ_0 or the corresponding frequency $f_0 \equiv 1/2\pi\tau_0$. The cited above figure Ref. [1, Fig. 54]: Open-Loop Gain vs. Frequency gives only the schematic representation how the low frequency approximation has to be used just as extrapolation from the low frequency domain. Only within the framework of this extrapolation we can call f_0 as approximately -3db bandwidth frequency of crossover frequency. We follow the language of Ref. [1] but strictly speaking in the present paper we present a method for determination of the frequency parameter f_0 and its Probability Distribution Function (PDF) for a series of hundred samples. PDF is actually the integrated histogram which is often more informative for descriptive statistics.

In the general case, however, the low frequency approximation Eq. (9) has to be substituted by an adequate Padé approximant

$$G^{-1}(s) = \left(\frac{1}{G_0} + s\tau_0\right) \frac{P_n(s)}{P_m(s)},$$
(9)

where the polynomials in the numerator and the denominator start from a constant term one and $P_n(0) = P_m(0) = 1$. This correction giving the exact formula is negligible, for example, for a static amplification according Eq. (1) with R/r > 10. But of course in the general case the single pole approximation Eq. (9) is inadequate for high-frequency applications. In order to have adequate description, we have to know a good parameterized function $G^{-1}(s)$, which is specific for each operational amplifier. However, the low frequency approximation used for example in Ref. ([1]) is universal. In the next section we describe a method for determination of f_0 and further we represent the statistical distribution of this important for the operational amplifiers parameter.

IV. EXPERIMENT WITH CLOSED-LOOP SCHEMATIC FOR DETERMINATION OF f_0

There is no doubt that the engineers from those times were familiar with operational calculus and complex analysis. But that is not the case for the contemporary textbooks in electronics entitled in the style "The Handicraft of Electronics" addressed to users abhorring complex numbers and differentiation. This probably is the main reason a method for the crossover frequency f_0 measurement not to be described. A method for determination of f_0 is well described in the book by Dostal [3, Chap. 5, Sec. 5.2.2, Fig. 5.11, p. 150]. However despite this textbook explanation as a rule most of the users are unable to determine f_0 , and many of producers of operational amplifiers are giving in the specifications values of f_0 significantly differing from the measured values.

One of the goals of the current work is a simple method for the determination of τ_0 and f_0 . Let introduce the modulus of the complex amplification function $Y(\omega) \equiv |\Upsilon(\omega)|$. When s is purely imaginary, from Eq. (1) we obtain

$$\frac{1}{Y^2(f)} = \frac{|U_{\rm I}|^2}{|U_0|^2} = \frac{1}{\left(\frac{R}{r}+1\right)^2} + \frac{f^2}{f_0^2}.$$
 (10)

Experimental data in the Y^{-2} versus f^2 plane for operational amplifier ADA4898-2 [11] are depicted in Fig. 1.

A simplified method for quick determination of f_0 without using a linear regression is also shown in Fig. 1. For a relatively small frequency (1 kHz for instance), the amplification Y_0 is measured and next the frequency $f_{1/n}$ is measured, for which the amplification $Y(f_{1/n})$ is n times smaller than Y_0 ,



Fig. 1. Typical experimental data for the square of the reciprocal modulus of the amplification Y as a function of the square of the frequency f. The high correlation coefficient $\rho = 0.9997$ gives a hint for a high accuracy of the work of the Manhattan equation for operational amplifiers Eq. (8) and the including of the next frequency dependent term is not necessary. The slope of the line gives for a the used ADA4898-2 $f_0 = 39.6$ MHz. The values of the resistors used for the non-inverting amplifier are $R = 1989 \Omega$ and $r = 20.1 \Omega$. The deviation of the data from the interpolating line substitute error bars. The experimental data processing using linear regression significantly increases the accuracy for determination of f_0 with respect of other methods described in the textbooks. The linear dependence is an algebraic result of the time dependent master equation for operational amplifiers Eq. (8).

i.e. $Y(f_{1/n}) = Y_0/n$. For the illustrative example from Fig. 1 and n=2, the crossover frequency is

$$f_0 = \frac{1}{\sqrt{3}} \left(\frac{R}{r} + 1\right) f_{1/2}.$$
 (11)

In this way using a dozen ADA4898-2 we obtained $f_0 = (46.6 \pm 1.3)$ MHz or the separate operational amplifiers have approximately 3% fluctuations created by uncertainty of our output voltage 1 V_{p-p} measured by oscilloscope Hitachi V-252; cf. the values pointed out in the specification [11]. A signal generator Rigol DG1022 was used for a source of of the test signal of typically with amplitude of 1 V passed trough voltage divider and later recovered by the amplifier. As

$$10^{-3/10} - \frac{1}{\left(\sqrt{2}\right)^2} \approx 1.19 \times 10^{-3} \ll 1,$$

re-denoting for closed-loop gain and $n = \sqrt{2}$

$$f_{-3\mathrm{dB}} \equiv f_{1/\sqrt{2}}, \quad f_{\mathrm{CROSSOVER}} \equiv f_0, \quad R_{\mathrm{F}} = R, \quad R_{\mathrm{G}} = r,$$

we arrive at Eq. (9) of Ref. [1] written in the original notations

$$f_{\rm CROSSOVER} = \frac{R_{\rm F} + R_{\rm G}}{R_{\rm G}} f_{-3\rm dB}.$$
 (12)

The formula corresponding to $1/Y^2 = 2$ in Fig. 1 is an exact solution in the framework of the use of the master equation Eq. (8).

Another measurements set of using the same equation with master but now an Anfatec USB Lockin 250 kHz amplifier[16] are made. The Lockin amplifier applies its reference signal first to a simple repeater circuit with an ADA4898-2 amplifier, then to 100 times voltage divider and finally to the non-inverting amplifier with static amplification 101, which contains the measured



Fig. 2. A schematic of the circuit for the crossover frequency f_0 measurement with an Anfatec Lockin amplifier. The circuit consists of a repeater with a ADA4898-2 operational amplifier, followed by a voltage divider with $R_1 = R = 1 \ k\Omega$ and $R_2 = r = 10 \ \Omega$ and a non-inverting amplifier with the ADA4898-2 whose f_0 is to be measured. The Lockin reference signal is $U_{\rm I}$ and the output signal going back to the Lockin is U_0 . The power supply voltage is omitted for brevity, the used supply voltage for both operational amplifiers is $\pm 9 \ V$ with the described capacitors in the ADA4898 specifications [11]. The static amplification is significant $R/r = 100 \gg 1$ and this ensures applicability of the universal master equation for the operational amplifiers Eq. (8).

ADA4898-2 as shown in Fig. 2. The repeater and noninverting amplifier are placed in a screening metal box from STR8 after shave lotion with both input and output coax cables going to the lock-in amplifier (if necessary authors will provide a picture of the set-up). Also, the set-up includes an appropriate switch for the selection of only one output signal from the double operational amplifiers at a time. Having this set-up and performing N = 400 measurements (200 ADA4898-2), the obtained results are shown in Fig. 3. The



Fig. 3. For the first time in electronics: probability distribution function of the measurements of the crossover frequency f_0 for 200 ADA4898-2 (double) amplifiers. The experimental data are shown with the dots and fitted error function is shown by a continuous line line. The abscissa is the dimensionless deviation from the mean value $\Delta f / \sigma_f$, where $\Delta f = f_i - \overline{f}$, $\overline{f} = 97.73$ MHz is the average frequency and $\sigma_f = \langle (f_i - \overline{f})^2 \rangle = 1.62$ MHz is the standard deviation, where the angle brackets mean division of the sum in the brackets by N - 1, where N = 400 is the number of the measurement i and the total number of measurements N. The difference between the experimental distribution (dots) and analytic fit (line), i.e. the Kolmogorov criterion [17], [18] reveals that the distributions has a correlation coefficient 0.996. Finally to conclude $\sigma_f/\overline{f} = 1.66\%$.

average cutoff frequency $\overline{f_0} = 97.73$ MHz and its standard deviation $\sigma_f = \langle (f_i - \overline{f})^2 \rangle = 1.62$ MHz and $\sigma_f / \overline{f} = 1.66\%$. Finally to add some words for the actual measurement with the lock-in amplifier. The Anfatec USB Lockin 250 features a sweep frequency, which allows us to change the frequency of the reference signal and to measure its amplification by the non-inverting amplifier as a function of the frequency. In this way, we actually perform the same measurement as the first one with the generator and the oscilloscope (shown in Fig. 1) but with 512 points divided in a frequency range 10-100 kHz. For each single amplifier we perform the described in Fig. 1 linear regression with 512 points and obtain its crossover frequency f_i . The lowest correlation coefficient of all N = 400 linear regressions is 0.99935, which is an order of magnitude lower than all the rest larger than 0.9999.

In the specification [11], see Tables 1 and 2, our parameter f_0 corresponds to non-inverting amplifier with open $R_{\rm G}=\infty$ and closed $R_{\rm F}=0$ and Y(0)=1. For such an amplifier, according to Eq. (9) in [1] f_0 is closed-loop "–3 dB" frequency. In the specification [1] $f_{\rm CROSSOVER}$ is defined as frequency where the operational amplifier open-loop

$$|G(f_{\text{CROSSOVER}})| = 1,$$

or gain equals 0 dB. This notion corresponds to our f_0 parameter only if the dependence in Fig. 54 in [1] is a straight line. However in the Eq. (4-9) in this specification [1] the notion $f_{\text{CROSSOVER}}$ is used in the sense of our $f_0 = 1/2\pi\tau_0$ notation. As a parameter with dimension frequency describing the low frequency behavior of the electronic circuits with amplification $Y(\omega = 0) \gg 1$ which is the main domain of the operational amplifiers market. Engineers in electronics, who design devices working at frequencies much lower than f_0 , for a precise analysis need to evaluate the non-linearity corrections.

V. DISCUSSION AND CONCLUSIONS

The exact knowledge of the crossover frequency f_0 is necessary when we need to precisely determine the non-ideal effects of operational amplifiers. For instance, in cases when there is a need of an exact calculation of the pass bandwidth of amplifiers with active filters, the Manhattan equation is indispensable. We hope that our work will induce further tutorial descriptions in AnalogDialogue for the determination of the crossover frequency using graphical representation of the real data for operational amplifiers, for example $f_{\text{CROSSOVER}} =$ 410 MHz for ADA4817 [1], [11].

In short, the master equation for the operational amplifiers is present implicitly in electronic developments even before the notion *operational amplifier* to be coined but according to the best we know [3, Eq. (2.7a)], [12, Eq. (2.1)], [13, Eq. (2.24)],[14, Eq. (3.47)] and [15, Eq.(2.1)] this equation has never been published as an equation connecting time dependent input and output voltages; that is why Eq. (8) is a new one.

We apply this equation in the analysis of a simple circuit for measuring of the cut-off frequency of operational amplifiers. A new equation Eq. 10 has been derived and used to develop a new method for the measurement of f_0 . Using this new method, we observe significant differences in the values for cut-off frequencies given in the specification by the producer. Our measurements reveal high reliability, the correlation coefficient is larger than 0.999 and this reveals high accuracy for applicability of the master equation Eq. (8). This also means that including higher order terms and second poles in Eq. (8) is not justified since their influence would be hardly detectable and important.

The large difference in the results for f_0 obtained by both methods can have several explanations. The most plausible one is that the first measurement was done with oscilloscope probes for connectivity, which have low pass filters built-in and they introduced spurious frequency deflection. Another explanation is the screening, however this effect should not introduce a difference 2-3 times but at most around 10% in the kHz region.

The high correlation coefficient in Fig. 1 demonstrate that Eq. (10) is perfectly working consequence of the proposed master equation Eq. (8). Our method reveals that contemporary operational amplifiers have only 1-2% dispersion of the cut-off frequency. We made analogous measurements using many other operational amplifiers and obtained satisfactory work of our method based on Eq. (10).

In conclusion we suppose that our method for determination of the cut-off frequency based on the Manhattan equation for the operational amplifier can become a convenient tool for engineers developing new circuits. Our set-up can be built in every lab and can give many examples of derivation of new results using Eq. (8). If the culture for measurement of cutoff is popularized producer will more precise with giving in this parameter in the specifications, for some purposes 20% difference is significant.

In order to avoid misunderstandings we have to emphasize that the frequency parameter f_0 which determines circuits with high static amplification describes only the universal low frequency dependence of operational amplifiers. We present a reliably working method for determination of this important parameter and perhaps for first time we age presenting statistical properties of f_0 for a contemporary low-noise operational amplifier. For circuits with significant static amplification $\gg 1$ formulas with f_0 give adequate description of their frequency behavior.

ACKNOWLEDGMENT

The authors appreciate the cooperation with Vassil Yordanov in early stages of the present research, are grateful to Pancho Cholakov and Ginka Dinekova for suggesting the low noise ADA4898-2 operational amplifier and to Peter Todorov for providing us the possibility to measure 200 samples. The authors appreciate the dialog with the Principal Design Engineer / Design Manager Art Kalb through the AD EngineerZone.

REFERENCES

 Technical Specification ADA4817: Low Noise, 1 GHz FastFET Op Amps, Rev. D. http://www.analog.com/static/imported-files/data_sheets/ ADA4817-1_4817-2.pdf.

- [2] K. G. McConnell and W. F. Riley, "Tools of tensometry" in A. S. Kobayashi, *Handbook on experimental mechanics*, (Prentice-Hall Inc., Seattle, Washington, 1987).
- [3] J. Dostál, Operational Amplifiers, (1st ed., Elsevier, New York, 1981).
- [4] A. V. Oppenheim, Editor, Signals and Systems, (Prentice Hall, New Jersey, 1996), Chap. 9, "Laplace transforms".
- [5] W. M. Siebert, *Circuits, Signals, and Systems* (MIT Press, Cambridge, Massachusetts, 1986), Chap. 4 Poles and Zeros, pp. 105-138.
- [6] H. W. Bode, "Relations between attenuation and phase in feedback amplifier design," Bell System Technical Journal, 19, pp. 421-454, (1940), http://cdn14.21dianyuan.com/download.php?id=73990.
- [7] E. Peterson, J. G. Kreer and L. A. Ware, *Regeneration Theory and Experiment*, Proc. of the I.R.E., 22, no. 10, pp. .681-700, (1934).
 [8] W. Jung, "Op Amp History", http://www.analog.com/media/en/
- W. Jung, "Op Amp History", http://www.analog.com/media/en/ training-seminars/design-handbooks/Op-Amp-Applications/SectionH. pdf.
- [9] J. R. Ragazzini, R. H. Randall and F. A. Russell, "Analysis of Problems in Dynamics by Electronic Circuits, Proc. of the I.R.E., 35, no. 5, pp. 444-452, (1947).
 [10] "John Ragazzini, 76, Educator and Engineer", The New York Times,
- [10] "John Ragazzini, 76, Educator and Engineer", The New York Times, November 24, 1988. http://www.nytimes.com/1988/11/24/obituaries/ john-ragazzini-76-educator-and-engineer.html.
- [11] Technical Specification ADA4898: High Voltage, Low Noise, Low Distortion, Unity-Gain Stable, High Speed Op Amp, Rev. E, http://www. analog.com/static/imported-files/data_sheets/ADA4898-1_4898-2.pdf.
- [12] G. W. Roberts and A. S. Sedra, *Spice*, 2nd ed., (Oxford University Press, New York, 1997).
- [13] M. S. Ghausi and K. R. Laker, Modern Filter Design: Active Rc And Switched Capacitor, (Institution of Engineering and Technology, 2003).
- [14] T. Deliyannis, Y. Sun, J. K. Fiddler, Continuous-Time Active Filter Design, (CRC-Press, New York, 1999).
- [15] P. V. A. Mohan, VLSI Analog Filters, (Springer, New York, 2013).
- [16] Anfatec Instruments AG 2013 USB LOCKIN 250 LOCKIN AMPLIFIER AMPLIFIER 10 mHz to 250 kHz Rev. 1.03 http://www.anfatec.net/ downloads/USBLockIn/USBLockIn250_Manual.pdf
- [17] N. L. Johnson and F. C. Leone, *Statistics and Experimental Design in Engineering and Physical Sciences*, Vol. 1, 2nd ed., (John Wiley & Sons, New York, 1977).
- [18] P. J. Bickel and K. J. Docksum, *Mathematical Statistics, Basic Ideas and Selected Topics*, (Holden-Day Inc., New York, 1977), Sec. 9.6.A Kolmogorov Criterion.