

Bottom-Fill Method for Stopping Leaking Oil Wells

Louis A. Bloomfield*

Department of Physics, University of Virginia, Charlottesville, Virginia 22904

(Dated: March 3, 2019)

Abstract

Hardware failure at the top of a deep underwater oil well can result in a catastrophic oil leak. The enormous pressure lifting the column of oil in that well makes it nearly impossible to stop from the top with seals or pressurization. We propose to fill the bottom of the well with dense and possibly streamlined objects that can descend through the rising oil. As they accumulate, those objects couple to the oil via viscous and drag forces and increase the oil's effective density. When its effective density exceeds that of the earth's crust, the oil will have essentially stopped flowing.

PACS numbers: 91.65.My,89.30.aj,47.85.Dh,47.85.L-

INTRODUCTION

The catastrophic oil leak that followed the destruction of the Deepwater Horizon drilling platform highlights the need for a reliable method of stopping the flow of oil from a crippled oil well. The failure of the “top kill” technique demonstrates that high-tech methods, particularly those that involve sealing or pressurizing the top of a damaged well, do not always work. Here, we propose a low-tech solution that is based on simple physics and has only two requirements: (1) an opening at the top of the well hole and (2) a large supply of dense, streamlined objects that can be dropped through that opening to descend by gravity alone to the bottom of the well.

STOPPING THE FLOW FROM THE TOP IS DIFFICULT

Since the earth’s crust has a density of roughly 2800 kg/m^3 , the ambient pressure 5 km below its surface is approximately $1.4 \cdot 10^8 \text{ Pa}$. A bottom pressure of only $4 \cdot 10^8 \text{ Pa}$ is needed to support the weight of a 5-km column of crude oil (800 kg/m^3). The difference between those two pressures, $1.0 \cdot 10^8 \text{ Pa}$ (15,000 psi), is the excess bottom pressure acting to lift the oil column in a 5 km deep oil well and thus the pressure one must apply to the top of that column to keep it from rising.[1] Put another way, oil is buoyant in the denser crust and keeping a 5 km column of oil from floating upward requires a top pressure of about $1.0 \cdot 10^8 \text{ Pa}$.

Applying that enormous pressure to the top of a damaged well is a difficult task, particularly underwater. The “top kill” technique attempts to apply so much pressure to the top of the well that the oil column actually flows downward and the oil is replaced by a denser fluid. With leaks allowing much of the dense fluid to escape, the pump responsible for pressurizing the top of the well may have to supply more than $0.1 \text{ m}^3/\text{s}$ of dense fluid at a pressure of more than 10^8 Pa —a pumping power (pressure times volume per second) of more than 10 MW (13,000 hp).

STOPPING THE FLOW FROM THE BOTTOM IS EASY

Rather than acting from the top of the well to stop the flow, our approach acts from the bottom. We propose filling the well with dense objects and thereby gradually increasing the

effective density of the fluid it contains. As the fluid's density increases, both its buoyancy and its flow rate decrease. When the fluid's effective density exceeds the density of the earth's crust, the flow rate will have dwindled close to zero.

We achieve that density increase not by replacing the oil with another fluid but by dropping high-density objects into the oil. On the length scale of the well hole, viscous and drag forces can couple the oil to those objects so that the hole is effectively filled with a high-density fluid. If iron objects (7900 kg/m³) are used, the flow should essentially stop when iron occupies about 30% of the well's volume.

The object-filled well resembles a “packed powder.” Oil flowing through the narrow channels in that powder dissipates ordered energy as it struggles against drag and viscous forces. The energy supplied to the oil by the enormous pressure beneath it is wasted as thermal energy and the upward momentum given to the oil by the bottom pressure is transferred to the objects and walls of the well.

The key challenge in this method is to ensure that the dense objects descend to the bottom of the well and accumulate there. Each object will descend only if its downward terminal velocity \mathbf{v}_t relative to the fluid is greater in magnitude than the upward velocity of that fluid \mathbf{v}_f . This requirement is fairly easy to achieve when $|\mathbf{v}_f|$ is 5 m/s or less and is still within reach when $|\mathbf{v}_f|$ is 20 m/s.

An object falling through an upward moving fluid reaches terminal velocity when the three forces acting on it, namely its downward weight \mathbf{W} , the upward drag force \mathbf{F}_D , and the buoyant force \mathbf{F}_B , sum to zero:

$$\mathbf{W} + \mathbf{F}_D + \mathbf{F}_B = 0. \quad (1)$$

The drag force can be approximated as:[2]

$$\mathbf{F}_D \simeq \frac{1}{2} \rho_f |\mathbf{v}|^2 \hat{\mathbf{z}} C_D A, \quad (2)$$

where ρ_f is the density of the fluid, \mathbf{v} is the downward velocity of the object relative to the fluid, C_D is the drag coefficient for the object in the fluid, and A is the effective cross-sectional area of the object.

A spherical object of radius r and density ρ_s has a downward weight given by

$$\mathbf{W} = -\frac{4}{3} \pi r^3 \rho_s g \hat{\mathbf{z}}, \quad (3)$$

TABLE I: Terminal velocities \mathbf{v}_t of iron spheres and iron teardrops falling through crude oil.

$ \mathbf{v}_t $ (m/s)	Sphere radius (cm)	Teardrop radius (cm)
1	0.5	
2	1	
5	5	0.6
10	20	2.6
20		10

where $-g\hat{\mathbf{z}}$ is the acceleration due to gravity. That sphere experiences an upward buoyant force equal in magnitude to the weight of the fluid it displaces:

$$\mathbf{F}_B = \frac{4}{3}\pi r^3 \rho_f g \hat{\mathbf{z}}. \quad (4)$$

If we insert the cross-sectional area for a sphere in Eq. 2, substitute Eqs. 2, 3, and 4 into Eq. 1, set $\mathbf{v} = \mathbf{v}_t$, and solve for r , we obtain the radius of the sphere as a function of its terminal velocity:

$$r \simeq \frac{3}{8} \frac{C_D |\mathbf{v}_t|^2}{g} \frac{\rho_f}{(\rho_s - \rho_f)} \quad (5)$$

A sphere is a hydrodynamically blunt object with a drag coefficient $C_D \simeq 3$ at Reynolds number $Re_d = 10$ and $C_D \simeq 0.5$ at $Re_d = 1000$. [2] Table I lists approximate terminal velocities for iron spheres ($\rho_s = 7900 \text{ kg/m}^3$) of various radii descending through crude oil ($\rho_f = 800 \text{ kg/m}^3$, dynamic viscosity $0.05 \text{ Pa}\cdot\text{s}$).

When the upward velocity of oil in the well hole is 5 m/s or less, fist-sized or smaller iron spheres will descend to the bottom of the well and accumulate there. Those initial spheres will reduce the upward velocity of the flow, allowing smaller spheres to follow. Eventually the flow will be so slow that even iron shot or sacks containing scrap iron and heavy mud will be able to descend into the well to curtail the flow.

For upward flows exceeding 5 m/s, however, hydrodynamically streamlined iron objects are necessary. Elongating an iron sphere into a teardrop shape can reduce its drag coefficient to $C_D \simeq 0.12$ at $Re_d > 100$, [2] while approximately doubling its weight and buoyancy. The terminal velocities of these streamlined iron teardrops are much greater than those of spheres, so smaller radii can be used (see Table I).

At upward flow rates exceeding 20 m/s, more elongated hydrofoils will be necessary. The

design of these hydrofoils is beyond our expertise, but it is likely that carefully designed iron hydrofoils can descend into wells with upward flow rates exceeding 30 m/s.

The well's excess bottom pressure transfers upward momentum to its column of fluid at a rate equal to the excess pressure times the cross-sectional area of the well. In a 5-km deep well, that momentum transfer could in principle send the oil upward at 500 m/s. Fortunately, no real well can sustain such a flow. Instead, the bottom pressure diminishes and much of the oil's upward momentum is transferred to the well walls via viscous interactions. The resulting flow is much more leisurely. When the well is also filled with small iron objects, those objects extract still more of the oil's upward momentum and slow it almost to a stop.

As each object descends through the oil at terminal velocity, it extracts upward momentum from the oil at a rate equal to its weight and it transfers that momentum to the earth via gravity. When the object settles onto the heap at the bottom of the well, however, its velocity relative to the oil decreases and its weight is partly supported by the heap. We might expect the rate at which the stationary object extracts upward momentum from the oil to be less than its weight, possibly much less.

Fortunately, several effects work together to maintain a high momentum transfer rate. First, a streamlined object is unlikely to settle in its most streamlined orientation. Second, oil flowing through the narrow channels between settled objects has a low Reynolds number and experiences greatly enhanced viscous drag (skin friction).

Third, as the objects pile up in the bottom of the well, they press tightly against the well walls. Since the surfaces are well-lubricated (naturally), friction plays a limited role. But the walls are not smooth, so objects can wedge themselves into nooks and crannies. These wedged objects can convey large amounts of upward momentum from the oil to the well walls.

To maximize the upward momentum transfer from the oil to the objects to the earth, it is prudent to choose objects that only barely descend into the rising oil and that, if possible, are relatively small and streamlined. They will then form the desired packed powder, couple strongly to the oil, and grip the walls of the well securely.

As the oil flow slows, smaller objects will be able to descend and we envision gradually reducing the sizes of the objects fed into the well. At each moment, an assortment of object sizes might be dropped into the well, allowing the well to choose which it keeps and to reject those with inadequate terminal velocities. One could even pour a random assortment of old

iron and steel hardware down the well hole, letting the well keep only those that manage to descend through the oil. Objects that can be streamlined easily, such as pieces of iron rebar with flattened tails to orient them in the flow, could be added to the mixture to strengthen the coupling between oil, objects, and walls.

Iron and steel objects are particularly cost effective, but denser materials could be used if necessary. Silver bullets come to mind. Iron is dense enough, however, that the average density in the well could easily be raised above 5000 kg/m^3 . With iron shot forming the top of that heap, it is unlikely that oil will be able to do more than trickle upward.

Lastly, deformable or crushable objects (e.g., lead or pig iron spheres) could be included in the mixture to strengthen the coupling between the object heap and the oil. It is important, however, that those objects not deform or crush before they are deeply buried in the heap and wedged against the walls. If they deform too easily and too soon, those objects may be lifted upward by increased drag forces and blown out of the well.

In summary, we propose to slow the flow of oil from a crippled oil well by filling that well with dense and possibly streamlined objects. The heavy heap of objects, wedged against the well walls, will couple strongly to the rising oil, wasting its energy and extracting its upward momentum. With properly chosen iron objects filling most of the volume of the well, the flow of oil will essentially stop.

* Electronic address: lab3e@virginia.edu

- [1] These values assume that hydrostatic pressure in the oil alone is supporting the weight of the crust overhead. Once some oil has been extracted from an underground reservoir, part of that weight is typically born by mineral formations and the oil pressure at the bottom of the well decreases.
- [2] P. P. Wegener, *What Makes Airplanes Fly* (Springer-Verlag, New York, 1991), ISBN 0-387-97513-6.