

Hydrothermal waves in evaporating sessile drops (APS 2009)

D. Brutin, F. Rigollet, C. LeNiliot

Aix-Marseille University, IUSTI Laboratory
13013 Marseille, FRANCE

May 17, 2022

Abstract

This fluid dynamics video was submitted to the Gallery of Fluid Motion for the 2009 APS Division of Fluid Dynamics Meeting in Minneapolis, Minnesota. Drop evaporation is a simple phenomena but still unclear concerning the mechanisms of evaporation. A common agreement of the scientific community based on experimental and numerical work evidences that most of the evaporation occurs at the triple line. However, the rate of evaporation is still empirically predicted due to the lack of knowledge on the convection cells which develop inside the drop under evaporation. The evaporation of sessile drop is more complicated than it appears due to the coupling by conduction with the heating substrate, the convection and conduction inside the drop and the convection and diffusion with the vapour phase. The coupling of heat transfer in the three phases induces complicated cases to solve even for numerical simulations. We present recent experimental fluid dynamics videos obtained using a FLIR SC-6000 coupled with a microscopic lens of $10\text{ }\mu\text{m}$ of resolution to observe the evaporation of sessile drops in infrared wavelengths. The range of 3 to $5\text{ }\mu\text{m}$ is adapted to the fluids observed which are ethanol, methanol and FC-72 since they are all half-transparent to the infrared.

1 Description

The movie sample presented is dealing with methanol sessile drops under evaporation. Three different fluids are used Methanol, Ethanol and FC-72. The original movie presented here is recorded with a resolution of 640x512

pixels. This movie is presented at real time speed (25 frames/sec). To fit the web site request, the video quality have been sharply reduced. For the three cases, the substrate is PFTE at constant surface temperature and with a surface roughness of 400 nm and no specific direction. The surface temperature is regulated to be constant using a PID heating device coupled with heating cartridges. The ambient temperature for all three cases is 25°C and the atmosphere is air at 1 atm.

Table 1: Physical properties of fluids at 25°C and 1 atm

	ρ_L	Cp	Lv	μ	σ	T_{sat}	Pr
	kg.m ⁻³	J.kg ⁻¹ .K ⁻¹	kJ.kg ⁻¹	mPa.s	mN.m ⁻¹	°C	-
Water	997	4180	2449	0.890	72.7	100	6.14
FC-72	1680	1100	88.0	0.638	12.0	56.0	12.3
Methanol	791	2531	1165	0.560	22.7	64.7	6.98
Ethanol	789	2845	841	1.095	22.0	78.0	22.3

Initially, the substrate is at a constant temperature. This is checked by the first image of the video. The thermal homogeneity is less than 1°C at the beginning the experiment. All fluids for these thickness are half-transparent. The different steps of a volatile drop evaporation can be distinguished as follow:

1. Phase 1 - Drop warming up - The start of the experiment is defined as the initial contact of the drop posed on the substrate. The first seconds of the experiments are characterized by a transition phenomena, the drop which was initially at room temperature is posed on a warm surface, the drop first is heated to reach almost the substrate temperature. The first step of the phenomena is thus only driven by the fluid heat capacity.
2. Phase 2 - Drop evaporation - The heat flux transferred to the drop reach a maximum value which correspond the beginning of our evaporation investigation. The drop is under evaporation, the heat flux linearly decrease during a first phase which correspond to the existence of convective cell inside the drop. The flow motion inside the drop depends on the fluid physical properties such as the fluid viscosity and latent heat of vaporization.

3. Phase 3 - Film evaporation - The last step of evaporation is characterized by the sharp decrease of the heat flux when the convection cells are vanished. No more fluid motion can be observed inside the drop. An explanation can be provided based on the critical thickness for thermal flow instabilities to develop.

Below, we present three experimental fluid dynamics videos for three different liquids with one objective: show up the complexity of drop evaporation mechanism.

1. In the case of Methanol, numerous hydrothermal waves can be observed at the first stage of the evaporation near the drop perimeter. In the center of the drop, the flow is much more unstable. The thermal flow motion inside the drop is fast, compared to the other fluids. The flow motion inside the drop stop when the drop reach 2 mm in diameter.
2. In the case of Ethanol, it is possible to observe with a greyscale evidence the temperature isotherm which are located in the middle of the drop. Near the drop perimeter, less hydrothermal waves are observed. Then during the evaporation, the thermal flow change very quickly to big hydrothermal waves inside the drop. The time of evaporation is comparable to the methanol case since the heat of vaporization is comparable.
3. In the case of FC-72, the latent of vaporization is at least 10 times smaller compared to methanol and ethanol. Consequently even with a substrate temperature at 29°C (slightly above the room temperature), the drop evaporation time is fast compared to the two other liquids. During the FC-72 evaporation, multiple internal convective cell structures can be observed which is completely different in the case of methanol and ethanol evaporation dynamics.

To conclude, for fluids with even comparable latent heat of vaporization, the thermal flow motion inside the drop can be very different since the fluid viscosity is the only important difference in the fluid physical properties. With the knowledge of the temperature scale, it is possible to relate the temperature difference inside the drop up to 10°C for methanol to the quick flow motion; where as for the ethanol drop, the maximum temperature difference is only 5°C. For very low heat of vaporization fluid (FC-72 for example) the dynamic of evaporation is completely different with quite

no more hydrothermal waves but several convection cells inside the drop. The FC-72 drop evaporation is closer to a FC-72 layer evaporation which is another research area of investigation.